


IRPB8a



For Parts Call Tools Renewed (800) 247-3639 Fax (860) 665-9821

IR PB8A

PART NO.	NAME OF PART
<b>HANDLE</b>	
81PB8	Throttle Lever Pin
16PB8A	Throttle Lever (New)
52CC4	Throttle Lever
81L29	Throttle Lever Stop Pin
81PB8	Throttle Lever Pin
85R71	Oil Plug
569PB8	Handle Bolt (4)
22A4H7	Handle Bolt Nut (4)
1128	Handle Bolt Washer
460PB6	Throttle Valve Bushing
15PB6	Throttle Valve
PE2110SP	Throttle Valve Spring
174JA45	Valve Chest Locating Pin
387PB6	Oil Regulating Pin
<b>CYLINDER</b>	
274PB8	Valve Guide
7PB8	Valve
A278J50	Valve Chest Dowel Pin
A94PB8	Valve Chest Bare Includes 5606
A65PB8A	Piston Light
65PB8	Piston Heavy Standard
715CC80	Inlet Nut Washer
112DB30W.D.	Cap
112CC80	Inlet Cap
49CC80	Cylinder Front Washer
57CC80	Anvil Block
19CC80	Hose Connection
1RPL-10	Valve Spring
<b>FRONTHEAD</b>	
418CC80	Fronthead Bolt Bare (2)
67CC80	Fronthead Bolt Spring (2)
468CC80	Fronthead Bolt Nut (2)
23CC3	Steel Retainer Lever Spring
66A4C8	Steel Retainer Lever Stop Nut
27OCC3	Steel Retainer Plug
26CC3	Steel Retainer Lever Bolt Bushing
222CC3	Steel Retainer Lever
240CC4	Steel Retainer Lever Bolt
IRPB8	Crust Breaker Tappet
A379PB8A	1 1/4 Hex. Fronthead Bushing
B379PB8A	1 1/4 Hex. Fronthead Bushing
E66PB8A	Bare Fronthead
998PB8A	Fronthead Incl. 5608-5609 1 1/4 Hex.
	Fronthead Incl. 5607-5609 1 1/8 Hex.