


THOR MODEL 423 60LB PAVING BREAKER



Item	Part Number	Description	Item	Part Number	Description
1	43523	Bolt Bushing	23	43395	Valve Stem Guide
2	43524	Retainer Bolt	24	43477	Dowel Pin
3	43414	Nut-FH Bolt	25	43896	Throttle Valve
4	43413	Lockwasher	27	43397	Spring-T.Valve
5	43412	Spring-F.H.	28	43510	Air Inlet Screen
6	43415	Bolt-F.H.	29	43512	Air Inlet Swivel
7	43441	Bolt-Back Head	30	45259	O-Ring
8	43431	Valve Chest-Front	31	43169	Air Inlet Swivel Nut
9	43186	Automatic Valve	32	52046	Cylinder
10	43432	Valve Chest-Rear	33	43436	Piston Hammer
11	43430	Valve Guide	34	43437	Tappet Seat
12	43474	Plunger	35	43408	Tappet
13	43475	Plunger Spring	36A	43449	Fronthead 1-1/4" Hex
14	47758	Back Head Bolt Nut		43451	Fronthead Assy 1-1/4"
15	68073	Oil Plug	36B	43448	Fronthead 1-1/8"
16	43473	Oil Control Felt		43450	Fronthead Assy 1-1/8"
17	43393	Lever Pin	37	43527	Steel Retainer
18	43428	Throttle Lever	38	43007	Lockwasher
19	52048	Back Head	39	43525	Retainer Bolt Nut
	12342	Back Head-Complete	40 (note)	43521	Spring (Mod 23554A Only)
20	43476	Handle Grip	40 (note)	99549	Spring (Mod 23553A Only)
21	52047	Oli Plug	41	99550	Plunger
22	82907	O-Ring	42	48385	Cylinder Plug